



1

Oblong Casseroles with Warmer



| # | size | dimensions | capacity |
|------|--------|-----------------|-------------|
| 911G | small | 40 x 20 x 20 cm | 1.5 litre |
| 912G | medium | 45 x 22 x 20 cm | 2.2 litre |
| 913G | large | 54 x 25 x 20 cm | 3 litre |
| 914G | double | 48 x 31 x 20 cm | 2x1.5 litre |



Oval Casseroles with Warmer

| # | size | dimensions | capacity |
|------|--------|-----------------|-----------|
| 919G | medium | 41 x 22 x 20 cm | 2.2 litre |
| 918G | large | 46 x 25 x 20 cm | 3 litre |




2

Square Casseroles with Warmer

| # | size | dimensions | capacity |
|------|--------|-----------------|-----------|
| 931G | medium | 34 x 24 x 20 cm | 2.2 litre |
| 932G | large | 42 x 28 x 20 cm | 3 litre |





3

Salad Bowl Set

| # | size | dimensions | capacity |
|------|-------|-----------------|----------|
| 991G | large | 27 x 27 x 17 cm | 3 litre |

Round Soup with Warmer

| # | size | dimensions | capacity |
|------|--------|-----------------|----------|
| 916G | small | 35 x 26 x 20 cm | 2 litre |
| 917G | medium | 35 x 27 x 26 cm | 3 litre |
| 915G | large | 35 x 25 x 29 cm | 4 litre |



Tray Set

| # | size | dimensions |
|------|--------|------------|
| 921G | small | 47 x 28 cm |
| 922G | medium | 53 x 32 cm |
| 923G | large | 59 x 35 cm |
| 943G | oval | 59 x 35 cm |



Tea Cup Set with Warmer

| # | dimensions |
|------|-----------------|
| 971G | 16 x 18 x 32 cm |
| 981G | 10 x 10 x 9 cm |



Oblong Casseroles with Warmer



| # | size | dimentions | capacity |
|-------|--------|-----------------|-------------|
| 911RG | small | 40 x 20 x 20 cm | 1.5 litre |
| 912RG | medium | 45 x 22 x 20 cm | 2.2 litre |
| 913RG | large | 54 x 25 x 20 cm | 3 litre |
| 914RG | double | 48 x 31 x 20 cm | 2x1.5 litre |



Oval Casseroles with Warmer




| # | size | dimentions | capacity |
|-------|--------|-----------------|-----------|
| 919RG | medium | 41 x 22 x 20 cm | 2.2 litre |
| 918RG | large | 46 x 25 x 20 cm | 3 litre |

Square Casseroles with Warmer



| # | size | dimentions | capacity |
|-------|--------|-----------------|-----------|
| 931RG | medium | 34 x 24 x 20 cm | 2.2 litre |
| 932RG | large | 42 x 28 x 20 cm | 3 litre |





Round Soup with Warmer

| # | size | dimensions | capacity |
|-------|--------|-----------------|----------|
| 916RG | small | 35 x 26 x 20 cm | 2 litre |
| 917RG | medium | 35 x 27 x 26 cm | 3 litre |
| 915RG | large | 35 x 25 x 29 cm | 4 litre |

Salad Bowl Set

| # | size | dimensions | capacity |
|-------|-------|-----------------|----------|
| 991RG | large | 27 x 27 x 17 cm | 3 litre |



7

Tray Set

| # | size | dimensions |
|-------|--------|------------|
| 921RG | small | 47 x 28 cm |
| 922RG | medium | 53 x 32 cm |
| 923RG | large | 59 x 35 cm |
| 943RG | oval | 59 x 35 cm |



Tea Cup Set with Warmer

| # | dimensions |
|-------|-----------------|
| 971RG | 16 x 18 x 32 cm |
| 981RG | 10 x 10 x 9 cm |





Oblong Casseroles with Warmer



| # | size | dimensions | capacity |
|-------|--------|-----------------|-------------|
| 911SG | small | 40 x 20 x 20 cm | 1.5 litre |
| 912SG | medium | 45 x 22 x 20 cm | 2.2 litre |
| 913SG | large | 54 x 25 x 20 cm | 3 litre |
| 914SG | double | 48 x 31 x 20 cm | 2x1.5 litre |



Square Casseroles with Warmer

| # | size | dimensions | capacity |
|-------|--------|-----------------|-----------|
| 931SG | medium | 34 x 24 x 20 cm | 2.2 litre |
| 932SG | large | 42 x 28 x 20 cm | 3 litre |

10

Oval Casseroles with Warmer

| # | size | dimensions | capacity |
|-------|--------|-----------------|-----------|
| 919SG | medium | 41 x 22 x 20 cm | 2.2 litre |
| 918SG | large | 46 x 25 x 20 cm | 3 litre |





11

Round Soup with Warmer

| # | size | dimensions | capacity |
|-------|--------|-----------------|----------|
| 916SG | small | 35 x 26 x 20 cm | 2 litre |
| 917SG | medium | 35 x 27 x 26 cm | 3 litre |
| 915SG | large | 35 x 25 x 29 cm | 4 litre |

Salad Bowl Set

| # | size | dimensions | capacity |
|-------|-------|-----------------|----------|
| 991SG | large | 27 x 27 x 17 cm | 3 litre |

Tray Set

| # | size | dimensions |
|-------|--------|------------|
| 921SG | small | 47 x 28 cm |
| 922SG | medium | 53 x 32 cm |
| 923SG | large | 59 x 35 cm |
| 943SG | oval | 59 x 35 cm |



Tea Cup Set with Warmer

| # | dimensions |
|-------|-----------------|
| 971SG | 16 x 18 x 32 cm |
| 981SG | 10 x 10 x 9 cm |





Oblong Casseroles with Warmer

| # | size | dimensions | capacity |
|--------|--------|-----------------|-------------|
| 1011BL | small | 40 x 20 x 20 cm | 1.5 litre |
| 1012BL | medium | 45 x 22 x 20 cm | 2.2 litre |
| 1013BL | large | 54 x 25 x 20 cm | 3 litre |
| 1014BL | double | 48 x 31 x 20 cm | 2x1.5 litre |



Round Soup with Warmer

| # | size | dimensions | capacity |
|--------|-------|-----------------|----------|
| 1015BL | large | 35 x 25 x 29 cm | 4 litre |



Salad Bowl Set

| # | size | dimensions | capacity |
|--------|-------|-----------------|----------|
| 1091BL | large | 27 x 27 x 17 cm | 3 litre |

Tray Set

| # | size | dimensions |
|-------|--------|------------|
| 921BL | small | 47 x 28 cm |
| 922BL | medium | 53 x 32 cm |
| 923BL | large | 59 x 35 cm |
| 943BL | oval | 59 x 35 cm |



Tea Cup Set with Warmer

| # | dimensions |
|-------|-----------------|
| 971BL | 16 x 18 x 32 cm |
| 981BL | 10 x 10 x 9 cm |





Oblong Casseroles with Warmer

| # | size | dimensions | capacity |
|-------|--------|-----------------|-------------|
| 1011S | small | 40 x 20 x 20 cm | 1.5 litre |
| 1012S | medium | 45 x 22 x 20 cm | 2.2 litre |
| 1013S | large | 54 x 25 x 20 cm | 3 litre |
| 1014S | double | 48 x 31 x 20 cm | 2x1.5 litre |

Oval Casseroles with Warmer

| # | size | dimensions | capacity |
|-------|--------|-----------------|-----------|
| 1019S | medium | 41 x 22 x 20 cm | 2.2 litre |
| 1018S | large | 46 x 25 x 20 cm | 3 litre |

Round Soup with Warmer

| # | size | dimensions | capacity |
|-------|-------|-----------------|----------|
| 1015S | large | 35 x 25 x 29 cm | 4 litre |



Tray Set

| # | size | dimensions | capacity |
|------|--------|------------|----------|
| 921S | small | 47 x 28 cm | - |
| 922S | medium | 53 x 32 cm | - |
| 923S | large | 59 x 35 cm | - |
| 943S | oval | 59 x 35 cm | - |



Tea Cup Set with Warmer

| # | size | dimensions | capacity |
|------|------|-----------------|----------|
| 971S | - | 16 x 18 x 32 cm | - |
| 981S | - | 10 x 10 x 9 cm | - |

16



Salad Bowl Set

| # | size | dimensions | capacity |
|-------|-------|-----------------|----------|
| 1091S | large | 27 x 27 x 17 cm | 3 litre |